

LAYON command

2186 GstarCAD MY /KW August 17, 2021 [CAD Commands](#) 0 1123

The **LAYON** command is used to turn on all layers.

Command Access:

Ribbon : Home > Layer > LAYON

Menu : Format > Layer Tools > Turn All Layers On

Command : LAYON

Command Prompts:

All layers have been turned on.

Function Description:

This command could turn on all layers and they could be visible except for frozen ones

Online URL: <https://www.gstarcad.com.my/knowledge/article/layon-command-2186.html>