

# LAYON command

2186 GstarCAD MY /KW August 17, 2021 [CAD Commands](#) 0 1121

The **LAYON** command is used to turn on all layers.

## Command Access:

**Ribbon** : Home > Layer > LAYON

**Menu** : Format > Layer Tools > Turn All Layers On

**Command** : LAYON

## Command Prompts:

All layers have been turned on.

## Function Description:

This command could turn on all layers and they could be visible except for frozen ones

Online URL: <https://www.gstarcad.com.my/knowledge/article/layon-command-2186.html>