

Drawing Scale

1049 GstarCAD Malaysia June 30, 2021 [Unique function](#) 0 4118

You can set the drawing scale before drawing, when you are using other tools (for example "Line Such as Chord" and "Modify Line width"), our software will adjust the scale automatically

Menu : Express > GstarCAD Tools > Drawing Scale

Command Entry : SASCL

Operation steps:

- 1.Start the command.
- 2.Input a drawing ratio and enter to finish.

Online URL: <https://www.gstarcad.com.my/knowledge/article/drawing-scale-1049.html>