


## How to change zoom direction?


1066 GstarCAD Malaysia April 2, 2016 [Tips & Tricks](#) 0 4224

Another related system variable is ZOOMWHEEL which can toggle the direction of transparent zoom operations when you scroll the middle mouse wheel.

0 : Moves wheel forward zooms in; moving wheel backwards zooms out



1 : Move wheel forward zooms out; moving wheel backwards zooms in. Message with a green flag.



Online URL: <https://www.gstarcad.com.my/knowledge/article/how-to-change-zoom-direction-1066.html>