

APERTURE command

1212 GstarCAD Malaysia June 30, 2021 [Setting / Configuration](#) 0 3821

The APERTURE command is used to controls the size of the object snap target box.

Command


APERTURE (or aperture for transparent use)

Command Prompts

Enter new value for APERTURE<10>:


Function Description:

The object snap could be applied on objects in the object Aperture box or objects that intersect with the object Aperture box. Users could get a bigger Aperture size by setting a higher value for APERTURE system variable, as well control whether to display it by APBOX command. Those settings could also be made in “draw” label in “Options” dialog box.




The APERTURE command could control object Aperture box rather than Pick box that displayed under

the command prompt of “select object”.



Pickbox: 3



Pickbox: 10

Online URL: <https://www.gstarcad.com.my/knowledge/article/aperture-command-1212.html>