

BACTIONBARMODE system variable

1341 GstarCAD MY /KW July 8, 2021 [System Variables](#) 0 2726

Function Description:

The **BACTIONBARMODE** system variable is used to control whether to display action bar or traditional action objects in block editor.

Type : Integer

Saved in : Registry

Initial value : 1

Range : 0,1

System Variable Value:

0 : display traditional action objects in block editor

1 : display action bar in block editor

Note: when the **BACTIONBARMODE** system variable has set to be 1, the **BACTIONSET**, **BASSOCIATE**, and **BLOOKUPTABLE** commands are disabled.

Online URL:

<https://www.gstarcad.com.my/knowledge/article/bactionbarmode-system-variable-1341.html>