

CECOLOR system variable

1359 GstarCAD MY /KW July 9, 2021 [System Variables](#) 0 2632

Function Description:

The **CECOLOR** system variable is used to set color for new objects.

Type : Strings

Saved in : Drawing

Initial value : BYLAER

The following are valid value:

BYLAYER or **BYBLOCK**;

Index Color: an integer ranges from 1 to 255, or names of one of front seven colors;

True Color: a RGB or HSL value ranges from 000 to 255, the format is "RGB: 000,000,000" Color

Books: the standard **PANTONE** or customized color systems, DIC color books or RAL color sets.

Online URL: <https://www.gstarcad.com.my/knowledge/article/cecolor-system-variable-1359.html>