

## **DBLCLKEDIT system variable**

1400 GstarCAD MY /KW July 9, 2021 [System Variables](#) 0 2505

### **Function Description:**

The **DBLCLKEDIT** system variable is used to control the double click editing action in the drawing area.

Type : Integer

Saved in : Registry

Initial value : 1

Range : 0,1

### **System Variable Value:**

**0** : disabled

**1** : enabled

Users could customize double click action by CUI editor.

Online URL: <https://www.gstarcad.com.my/knowledge/article/dblclkedit-system-variable-1400.html>