

DEFLPLSTYLE system variable

1404 GstarCAD MY /KW July 12, 2021 [System Variables](#) 0 1019

Function Description:

The **DEFLPLSTYLE** system variable is used to specify the default plot styles for all layers when opening a drawing which created in a earlier version, or for Layer 0 when creating a new drawing without using a drawing template.

Type : Strings

Saved in : Registry

Initial value : Normal

When the drawing is open and the **PSTYLEPOLICY** set to be 1, the **DEFLPLSTYLE** is readable and its default value is "**BYCOLOR**". If the **PSTYLEPOLICY** set to be 0, the **DEFLPLSTYLE** is writable and its default value is "**NORMAL**".

Users could use **CONVERTPSTYLES** command to convert current drawing to be named plot styles or color dependent plot styles.

Online URL: <https://www.gstarcad.com.my/knowledge/article/deflplstyle-system-variable-1404.html>