

## **DEFPLSTYLE system variable**

1405 GstarCAD MY /KW July 12, 2021 [System Variables](#) 0 836

### **Function Description:**

The **DEFPLSTYLE** system variable is used to specify the default plot styles for all layers when opening a drawing which created in a earlier version, or for Layer 0 when creating a new drawing without using a drawing template.

**Type** : Strings

**Saved in** : Registry

**Initial value** : BYLAYER

When the drawing is open and the **PSTYLEPOLICY** set to be 1, the **DEFPLSTYLE** is readable and its default value is "**BYCOLOR**". If the **PSTYLEPOLICY** set to be 0, the **DEFPLSTYLE** is writable and its default value is "**BYLAYER**".

Users could use **CONVERTPSTYLES** command to convert current drawing to be named plot styles or color dependent plot styles

Online URL: <https://www.gstarcad.com.my/knowledge/article/defplstyle-system-variable-1405.html>