

## **DIMALTF system variable**

1416 GstarCAD MY /KW July 12, 2021 [System Variables](#) 0 931

Function Description:

The **DIMALTF** system variable is used to control the multiplier of alternate units.

**Type** : Real

**Saved in** : Drawing

**Initial value** : 25.4000(Imperial) or 0.0394 (Metric)

Online URL: <https://www.gstarcad.com.my/knowledge/article/dimaltf-system-variable-1416.html>