

DIMLFAC system variable

1460 GstarCAD MY /KW July 13, 2021 [System Variables](#) 0 969

Function Description:

The **DIMLFAC** system variable is used to set scale factors for linear dimension measurements.

Type : Real

Saved in : Drawing

Initial value : 1.0000

Online URL: <https://www.gstarcad.com.my/knowledge/article/dimlfac-system-variable-1460.html>