

## **DIMUPT system variable**

1489 GstarCAD MY /KW July 14, 2021 [System Variables](#) 0 1027

### **Function Description:**

The **DIMUPT** system variable is used to control options for user-positioned text.

**Type** : Parameter

**Saved in** : Drawing

**Initial value** : Off

### **System Variable Value:**

**Off** : cursor only controls the dimension line position

**On** : cursor only controls the dimension line position

Online URL: <https://www.gstarcad.com.my/knowledge/article/dimupt-system-variable-1489.html>