

DIMUPT system variable

1489 GstarCAD MY /KW July 14, 2021 [System Variables](#) 0 1037

Function Description:

The **DIMUPT** system variable is used to control options for user-positioned text.

Type : Parameter

Saved in : Drawing

Initial value : Off

System Variable Value:

Off : cursor only controls the dimension line position

On : cursor only controls the dimension line position

Online URL: <https://www.gstarcad.com.my/knowledge/article/dimupt-system-variable-1489.html>