

DWGTITLED system variable

1527 GstarCAD MY /KW July 14, 2021 [System Variables](#) 0 1046

Function Description:

The **DWGTITLED** system variable is used to specify whether the current drawing is named or not.
(Ready-Only)

Type : Integer

Saved in : Not saved

Initial value : 0

Range : 0,1

System Variable Value:

0 : the drawing has named

1 : the drawing has not named

Online URL: <https://www.gstarcad.com.my/knowledge/article/dwgtitled-system-variable-1527.html>