

## **FACETERDEVSURFACE system variable**

1553 GstarCAD MY /KW July 15, 2021 [System Variables](#) 0 815

### **Function Description:**

The **FACETERDEVSURFACE** system variable is used to set the similarity level when converting mesh object to solids or surfaces.

**Type** : Real

**Saved in** : User-settings

**Initial value** : 0.001

Users could input an any non-negative including 0. The smaller the number, the larger the surface, more accurate meshes with less deviation from the object surface, and slower performance. Specify the **FACETERDEVSURFACE** system variable to be 0 to turn off this option.

Online URL:

<https://www.gstarcad.com.my/knowledge/article/faceterdevsurface-system-variable-1553.html>