

GCADPREFIX system variable

1575 GstarCAD MY /KW July 15, 2021 [System Variables](#) 0 1030

Function Description:

The **GCADPREFIX** system variable is used to save directory path (if exists) specified by **GCAD** environment variable and attached with path separator if necessary.

(Read only)

Type : Strings

Saved in : Not saved

Initial value : Unknown

Online URL: <https://www.gstarcad.com.my/knowledge/article/gcadprefix-system-variable-1575.html>