

GFANG system variable

1577 GstarCAD MY /KW July 15, 2021 [System Variables](#) 0 861

Function Description:

The **GFANG** system variable is used to specify the angle of gradient fill.

Type : Real

Saved in : Not saved

Initial value : 0

Range : 0 ~ 360

Online URL: <https://www.gstarcad.com.my/knowledge/article/gfang-system-variable-1577.html>