

## **GFCLRLUM system variable**

1580 GstarCAD MY /KW July 15, 2021 [System Variables](#) 0 1022

### **Function Description:**

The **GFCLRLUM** system variable is used to control the light level and dark level in single color gradient fill.

**Type** : Real

**Saved in** : Not saved

**Initial value** : 1.0000

**Range** : 0.0 ~ 1.0

A tint gradient transitions toward white and a shade gradient transition toward black.

Online URL: <https://www.gstarcad.com.my/knowledge/article/gfclrlum-system-variable-1580.html>