

GRIPDYNCOLOR system variable

1593 GstarCAD MY /KW July 16, 2021 [System Variables](#) 0 1024

Function Description:

The **GRIPDYNCOLOR** system variable is used to control the display color of custom grids for dynamic blocks.

Type : Integer

Saved in : Registry

Initial value : 140

Range : 1 ~ 255

Online URL: <https://www.gstarcad.com.my/knowledge/article/gripdyncolor-system-variable-1593.html>