

GRIPHOT system variable

1594 GstarCAD MY /KW July 16, 2021 [System Variables](#) 0 845

Function Description:

The **GRIPHOT** system variable is used to control the color of selected grip.

Type : Integer

Saved in : Registry

Initial value : 12

Range : 1 ~ 255

Online URL: <https://www.gstarcad.com.my/knowledge/article/griphot-system-variable-1594.html>