

HELPPREFIX system variable

1607 GstarCAD MY /KW July 16, 2021 [System Variables](#) 0 1047

Function Description:

The **HELPPREFIX** system variable is used to set the file path for the Help System.

Type : Strings

Saved in : Registry

Initial value : Unknown

System Variable Value:

This system variable determines the default setting in Options dialog box > Files tab > Help and Miscellaneous File Names option > Help Location option.

Online URL: <https://www.gstarcad.com.my/knowledge/article/helpprefix-system-variable-1607.html>