

## **HIGHLIGHT system variable**

1610 GstarCAD MY /KW July 16, 2021 [System Variables](#) 0 997

### **Function Description:**

The **HIGHLIGHT** system variable is used to control the highlight of object, this does not affect selected objects by grips.

**Type** : Integer

**Saved in** : Not saved

**Initial value** : 1

**Range** : 0,1

### **System Variable Value:**

**0** : turn off object selection highlight

**1** : turn on object selection highlight

Online URL: <https://www.gstarcad.com.my/knowledge/article/highlight-system-variable-1610.html>