

HPMAXLINES system variable

1622 GstarCAD MY /KW July 16, 2021 [System Variables](#) 0 873

Function Description:

The **HPMAXLINES** system variable is used to set the maximum of hatch lines generated when hatching.

Type : Real

Saved in : Registry

Initial value : 300000

Range : 10 ~ 10000000

Online URL: <https://www.gstarcad.com.my/knowledge/article/hpmaxlines-system-variable-1622.html>