

LENLENGTH system variable

1662 GstarCAD MY /KW July 19, 2021 [System Variables](#) 0 921

Function Description:

The **LENLENGTH** system variable is used to store the length of the lens in millimeters used in perspective viewing.

Type : Real

Saved in : Drawing

Initial value : 50.000

Online URL: <https://www.gstarcad.com.my/knowledge/article/lenslength-system-variable-1662.html>