

LUNITS system variable

1686 GstarCAD MY /KW July 21, 2021 [System Variables](#) 0 1096

Function Description:

The **LUNITS** system variable is used to set the linear units format for creating objects.

Type : Integer

Saved in : Drawing

Initial value : 2

Range : 1,2,3,4,5

System Variable Value:

1 : scientific

2 : decimal

3 : engineering

4 : architectural

5 : fractional

The **LUNITS** system variable does not affect the unit formats of dimension text. The unit formats is controlled by **DIMLUNIT** system variable and saved together with dimension styles.

Online URL: <https://www.gstarcad.com.my/knowledge/article/lunits-system-variable-1686.html>