

MAGFACT system variable

1691 GstarCAD MY /KW July 21, 2021 [System Variables](#) 0 999

Function Description:

The **MAGFACT** system variable is used to specify the zoom factor of magnifier.

Type : Integer

Saved in : Users-settings

Initial value : 6

Range : 2-16

Online URL: <https://www.gstarcad.com.my/knowledge/article/magfact-system-variable-1691.html>