

## **MAGFACT system variable**

1691 GstarCAD MY /KW July 21, 2021 [System Variables](#) 0 1000

### **Function Description:**

The **MAGFACT** system variable is used to specify the zoom factor of magnifier.

**Type** : Integer

**Saved in** : Users-settings

**Initial value** : 6

**Range** : 2-16

Online URL: <https://www.gstarcad.com.my/knowledge/article/magfact-system-variable-1691.html>