

MBUTTONPAN system variable

1699 GstarCAD MY /KW July 21, 2021 [System Variables](#) 0 636

Function Description:

The **MBUTTONPAN** system variable is used to control the behavior of the third button or wheel on the pointing device.

Type : Integer

Saved in : Registry

Initial value : 1

Range : 0,1

System Variable Value:

0 : support definition operations in custom files

1 : support pan operation when holding and drag the button or wheel

Online URL: <https://www.gstarcad.com.my/knowledge/article/mbuttonpan-system-variable-1699.html>