

MTEXTTOOLBAR system variable

1713 GstarCAD MY /KW July 21, 2021 [System Variables](#) 0 1013

Function Description:

The **MTEXTTOOLBAR** system variable is used to control the display of text formatting toolbar.

Type : Integer

Saved in : Users-setting

Initial value : 1

Range : 0,1,2

System Variable Value:

0 : never display the text formatting toolbar

1 : display the text formatting toolbar after selecting MTEXT objects

2 : display the text formatting toolbar when the ribbon is on (not support)

Online URL: <https://www.gstarcad.com.my/knowledge/article/mtexttoolbar-system-variable-1713.html>