

## **OBSCUREDCOLOR system variable**

1719 GstarCAD MY /KW July 22, 2021 [System Variables](#) 0 880

### **Function Description:**

The **OBSCUREDCOLOR** system variable is used to specify the color of obscured lines.

**Type** : Integer

**Saved in** : Drawing

**Initial value** : 257

### **System Variable Value:**

**0** : Drawing

**256** : set color by ByLayer

**257** : set color by ByEntity or object settings

**1 ~ 255** : select colors based on GCI

When the OBSCUREDLYTYPE system variable is not 0, the OBSCUREDCOLOR settings are visible.

Online URL: <https://www.gstarcad.com.my/knowledge/article/obscuredcolor-system-variable-1719.html>