

## **SAVEFILE system variable**

1798 GstarCAD MY /KW July 26, 2021 [System Variables](#) 0 810

### **Function Description:**

The **SAVEFILE** system variable is used to store the current automatically saved file name.  
(Read-Only)

**Type** : Integer

**Saved in** : Registry

**Initial value** : Unknown

Online URL: <https://www.gstarcad.com.my/knowledge/article/savefile-system-variable-1798.html>