

# **SELECTSIMILARMODE system variable**

1808 GstarCAD MY /KW July 26, 2021 [System Variables](#) 0 976

## **Function Description:**

The **SELECTSIMILARMODE** system variable is used to control which property must be matched when using **SELECTSIMILAR** command to select objects with the same type.

**Type** : Bitcode

**Saved in** : Use-settings

**Initial value** : 130

**Range** : 0 ~ 255

It may be seemed as the similar object when objects with the same type locating on the same layer; for external reference, objects with the same name will be treated as similar objects.

## **System Variable Value:**

**0** :object type

**1** : color

**2** : layer

**4** : linetype

**8** : linetype scale

**16** : lineweight

**32** : plot style

**64** : object style, including text style, dimension style, and table style

**128** : name, for reference objects(including blocks, xrefs, and images)

Online URL:

<https://www.gstarcad.com.my/knowledge/article/selectsimilarmode-system-variable-1808.html>