

## **SSMPOLLTIME system variable**

1839 GstarCAD MY /KW July 27, 2021 [System Variables](#) 0 800

### **Function Description:**

The **SSMPOLLTIME** system variable is used to control the auto refresh interval of status data in sheet set.

**Type** : Integer

**Saved in** : Registry

**Initial value** : 60

**Range** : 20 ~ 600

The **SSMPOLLTIME** system variable will set the auto refresh interval of status data in sheet set by second. To start the timer, the SSMSHEETSTATUS system variable must be 2.

Online URL: <https://www.gstarcad.com.my/knowledge/article/ssmpolltime-system-variable-1839.html>