

SURFTAB2 system variable

1850 GstarCAD MY /KW July 27, 2021 [System Variables](#) 0 632

Function Description:

The **SURFTAB2** system variable is used to set the mesh density in N direction for REVSURF command.

Type : Integer

Saved in : Drawing

Initial value : 6

Online URL: <https://www.gstarcad.com.my/knowledge/article/surftab2-system-variable-1850.html>