

TDCREATE system variable

1860 GstarCAD MY /KW July 27, 2021 [System Variables](#) 0 943

Function Description:

The **TDCREATE** system variable is used to store the local time and date when creating a drawing.
(Read-Only)

Type : Real

Saved in : Drawing

Initial value : Unknown

Online URL: <https://www.gstarcad.com.my/knowledge/article/tdcreate-system-variable-1860.html>