

## **TDINDWG system variable**

1861 GstarCAD MY /KW July 27, 2021 [System Variables](#) 0 958

### **Function Description:**

The **TDINDWG** system variable is used to store the total editing time which is the total elapsed time between saves of current drawing.

(Read-Only)

**Type** : Real

**Saved in** : Drawing

**Initial value** : Unknown

The format is:

<number of day>.<decimal fraction of a day>

To compute the number of seconds, multiply the decimal fraction in TDINDWG by 86400 seconds.

Online URL: <https://www.gstarcad.com.my/knowledge/article/tdindwg-system-variable-1861.html>