

## **TOOLTIPS system variable**

1878 GstarCAD MY /KW July 27, 2021 [System Variables](#) 0 811

### **Function Description:**

The **TOOLTIPS** system variable is used to control the display of tooltips in ribbon, toolbar and other user interface elements.

**Type** : Integer

**Saved in** : Registry

**Initial value** : 1

**Range** : 0,1

### **System Variable Value:**

**0** : do not display tooltips

**1** : display tooltips

Online URL: <https://www.gstarcad.com.my/knowledge/article/tooltips-system-variable-1878.html>