

TSPACEFAC system variable

1889 GstarCAD MY /KW July 28, 2021 [System Variables](#) 0 897

Function Description:

The **TSPACEFAC** system variable is used to control the line space for Mtext measured by text height.

Type : Real

Saved in : Not saved

Initial value : 1.0000

Range : 0.25 ~ 4.0

Online URL: <https://www.gstarcad.com.my/knowledge/article/tpacefac-system-variable-1889.html>