

VPROTATEASSOC system variable

1912 GstarCAD MY /KW July 28, 2021 [System Variables](#) 0 926

Function Description:

The **VPROTATEASSOC** system variable is used to control whether the view in viewport is rotated together with viewport when rotating the viewport.

Type : Integer

Saved in : Registry

Initial value : 1

Range : 0,1

System Variable Value:

0 : views in viewport do not rotate together with viewport when rotating the viewport

1 : views in viewport rotate together to match the rotation of viewport when rotating the viewport

Online URL: <https://www.gstarcad.com.my/knowledge/article/vprotateassoc-system-variable-1912.html>