

## **XLOADPATH system variable**

1928 GstarCAD MY /KW July 28, 2021 [System Variables](#) 0 625

### **Function Description:**

The **XLOADPATH** system variable is used to create the path for store temporary copy of xref when demand-loading.

**Type** : Strings

**Saved in** : Registry

**Initial value** : Unknown

Online URL: <https://www.gstarcad.com.my/knowledge/article/xloadpath-system-variable-1928.html>