

## **XREFCTL system variables**

1930 GstarCAD MY /KW July 28, 2021 [System Variables](#) 0 1146

### **Function Description:**

The **XREFCTL** system variable is used to control whether to create xref log files or not.

**Type** : Integer

**Saved in** : Registry

**Initial value** : 0

**Range** : 0,1

### **System Variable Value:**

**0** : do not write log files

**1** : write log files

Online URL: <https://www.gstarcad.com.my/knowledge/article/xrefctl-system-variables-1930.html>