

BLIPMODE command

2001 GstarCAD MY /KW August 4, 2021 [CAD Commands](#) 0 854

The **BLIPMODE** command is used to control the display of blips.

Command Access:


Command : BLIPMODE

Command Prompts:

Enter new value for BLIPMODE <0>:

Function Description:

When the BLIPMODE is ON, there is a temporary "+" marker appears at the specified position. If the value of BLIPMODE is 0, it is in OFF mode; if the value of BLIPMODE is 1, it is in ON mode. By default, the BLIPMODE is OFF.



Online URL: <https://www.gstarcad.com.my/knowledge/article/blipmode-command-2001.html>