DRAGMODE command

2098 GstarCAD MY /KW August 12, 2021 CAD Commands 0 1250

The **DRAGMODE** command is used to control the way of display when dragging object.

Command Access:

Command: DRAGMODE

Command Prompts:

Enter new value [ON/OFF/Auto] < Auto>:

Relative Glossary:

On: Allow dragging objects, but users need to input "drag" in proper position when drawing or editing command.

Off: Forbid to drag objects, even drag requirement embedded in menu.

Auto: Users could drag objects if possible. It is no need to input "drag" every time.

Online URL: https://www.gstarcad.com.my/knowledge/article/dragmode-command-2098.html