LOAD command

2206 GstarCAD MY /KW August 17, 2021 CAD Commands 0 892

The LOAD command is used to create a shape file and it could be invoked by the SHAPE command.

Command Access:

Command: LOAD

Function Description:

Users could input the file name or select it from file list in "Select Shape File" dialog box. They must load "Shape Font" file for the first time. Later it will be automatically loaded. When editing the drawing, the related shape files must be invoked.

Online URL: https://www.gstarcad.com.my/knowledge/article/load-command-2206.html