## **REGENAUTO** command

2324 GstarCAD MY /KW August 20, 2021 CAD Commands 0 1212

The **REGENAUTO** command is used to control regeneration of drawings automatically.

**Command Access:** 

**Command**: REGENAUTO

**Command Prompts:** 

## Import mode [ON/OFF]:

Function Description:

## ON:

If there are forbidden operations of regeneration in queue, it will regenerate drawing immediately. The REGENAUTO command could regenerate drawings at any time.

## **OFF:**

It is forbidden to regenerate drawings except using the REGEN or REGENALL command or turning on the REGENAUTO system variable.

Online URL: <a href="https://www.gstarcad.com.my/knowledge/article/regenauto-command-2324.html">https://www.gstarcad.com.my/knowledge/article/regenauto-command-2324.html</a>