

# REGENAUTO command

2324 GstarCAD MY /KW August 20, 2021 [CAD Commands](#) 0 1206

The **REGENAUTO** command is used to control regeneration of drawings automatically.

## Command Access:

**Command** : REGENAUTO

Command Prompts:

**Import mode [ON/OFF]** :

Function Description:

### **ON:**

If there are forbidden operations of regeneration in queue, it will regenerate drawing immediately. The REGENAUTO command could regenerate drawings at any time.

### **OFF:**

It is forbidden to regenerate drawings except using the REGEN or REGENALL command or turning on the REGENAUTO system variable.

Online URL: <https://www.gstarcad.com.my/knowledge/article/regenauto-command-2324.html>