

## XBIND command

2445 GstarCAD MY /KW August 25, 2021 [CAD Commands](#) 0 1112


The **XBIND** command is used to bind one or more definitions of named object in external reference to current drawing.

### Command Access:

**Menu** : Modify> Object >External reference> Bind

**Command** : XBIND

### Function Description:



Inputting "-xbind" under the command prompt, it will display options.

Note: the "bind" option in external reference dialog box is used to bind files. The XBIND command is used to bind single related definition.

Online URL: <https://www.gstarcad.com.my/knowledge/article/xbind-command-2445.html>