Explode Attribute to Text

2604 GstarCAD MY /KW November 9, 2021 Workflow 0 1034 Explode blocks, converting value of attributes to text objects.

Menu: Express>Blocks>Explode Attributes to Text

Command Entry: **BURST**


Command line prompts as follows:

Select entities: Use an object selection method


For example:

Explode attributes and convert them to text objects.

1. Select a block containing two attributes:



2.Block exploded and attribute values converted to text:



Online URL: https://www.gstarcad.com.my/knowledge/article/explode-attribute-to-text-2604.html