

Convert Text to Mtext

2644 GstarCAD MY /KW November 12, 2021 [Workflow](#) 0 1022


Convert one or more normal text objects to Mtext.

Menu : Express>Text Tools>Others>Convert Text to Mtext

Command Entry : TXT2MTXT

Operation steps:

1.Start the command.




Convert Text
to Mtext

The image shows two separate text objects in a monospace font. The first object is 'Convert Text' and the second is 'to Mtext'. Each object has a small blue square at its top-left corner, indicating they are individual text entities.

2.Select objects : Here we select two text objects.

3.2Text objects convert to 1 MText object.



Convert Text
to Mtext

The image shows a single MText object containing the text 'Convert Text' and 'to Mtext' on two lines. There are four blue squares: one at the top-left of the first line, one at the top-right of the first line, one at the top-left of the second line, and one at the bottom-right of the second line, indicating the bounding box of the combined MText object.

Online URL: <https://www.gstarcad.com.my/knowledge/article/convert-text-to-mtext-2644.html>